RETROFIT OFFROAD

Hinge Steps for the MORryde JK HD Door Hinges

Installation Instructions

Tool required: 4mm or 5/32" Allen Wrench

Step 1: if your hinge came with the nut plate attached, remove the two screws holding the nut plate in place.

Step 2: Slip the nut plate inside the hinges; position it so both screw holes are visible.

Step 3: Attach the step to the hinge by inserting the screws through the step base and into the nut plate. Tighten well.

The step folds down for use and folds up for travel.









Easy access to your roof rack.

Steps can be installed on any hinge on any door. They can also be installed on the MORryde HD Tailgate Hinges if roof rack access is needed at the back of the Jeep.

