

Trail Kitchen Accessory: JP54-039



INSTALLATION INSTRUCTIONS

• **Tools Needed:** 7/16" Wrench 5/32" Allen wrench



STEP 1

Line up the holes in the Molle Bracket with the holes in the fridge tray.

MORryde



STEP 2

•Using the supplied 1/4 -20 button head bolts and nuts, fasten the Molle Bracket to the fridge tray.

HEAVY. DUTY. ADVENTURE.

www.MORryde.com • 574.293.1581